

111-141 COMMUNICATION PORTION

112 – 142 CONTROL PORTION


113, 123, 143a I/O PORTION 114 SENSOR

124 SWITCH

133, 143b DRIVE PORTION

134 LOAD

144 AUXILIARY EQUIPMENT MODULE




111a TRANSMITTING CIRCUIT

111c SUPERPOSING CIRCUIT

Fig 3 111b RECEIVING CIRCUIT - GND - +B 通信 COMMUNICATION LINE -150 151 通信 152 150 .AUXILIARY EQUIPMENT MODULE 制御 153b 151 **COMMUNICATION PORTION** 駆動 153 á 152 CONTROL PORTION 補機モジュール 153a I/O PORTION

153b DRIVE PORTION

下3.4




131a TRANSMITTING CIRCUIT

131b RECEIVING CIRCUIT

132a MICROCOMPUTER

132b CONTROL IC





131a TRANSMITTING CIRCUIT

131b RECEIVING CIRCUIT

131d FILTER

132a MICROCOMPUTER

132b CONTROL IC

Fig. 6








Fig.7





عوا





- 200 ECU
- 201 COMMUNICATION PORTION
- 202 CENTRALIZED CONTROL PORTION
- 204 POWER SUPPLY
- 213 I/O PORTION
- 233 DRIVE PORTION
- 114 SENSOR
- 124 SWITCH
- 134 LOAD